

Turbo shield sizes are based on two basic measurements, width and circumference. After measuring, refer to the sizing table below to find the correct size shield for your turbo.

Measurement 1: Outer circumference



Measurement 2: Housing width



	Outer Circumference:	Inner Width:	Weight:
GT22	14"-15"	1½" - 2"	0.52 lbs
GT25	15"-16"	2"-2½"	0.52 lbs